

NUMBER:	UG13007
CATEGORY:	User Guide
DATE:	29/07/2016
VERSION:	1.4

## Changing the System Time


### Introduction:

Panasonic KX-TDA/KX-TDE/KX-NCP/KX-NS\* Series PABX systems can have the time automatically updated via the exchange if connected via ISDN lines or by SNTP if connected to your data network. If the system is not connected to an ISDN line or on the data network, please follow the procedure below to update the system time.

**\*Note: PT programming is not available on the KX-NS1000.**


### Programming Procedure:

#### Step 1: Enter System Programming



**Note:** The default system password is **1234**.

#### Step 2: Set date and time (12hr format)



#### Step 3: Exit system Programming

