


NUMBER:	UG14006
CATEGORY:	User Guide
DATE:	29/07/2016
VERSION:	1.1

## Panasonic KX-NT553/KX-NT556 – Quick Reference Guide


### The Handset




- |                                |                                  |
|--------------------------------|----------------------------------|
| 1. LCD panel display (backlit) | 14. Hold                         |
| 2. Message waiting lamp        | 15. Intercom                     |
| 3. Programmable keys           | 16. SP-Phone                     |
| 4. Handset hook                | 17. Microphone                   |
| 5. Headset jack (corded)       | 18. Navigation panel             |
| 6. Pause                       | 19. Enter                        |
| 7. Conf (conference)           | 20. Soft keys                    |
| 8. Message                     | 21. EHS (Electronic hook-switch) |
| 9. Flash/Recall                | 22. FWD/DND                      |
| 10. Redial                     | 23. Cancel                       |
| 11. Auto Ans/Mute              | 24. Next Page                    |
| 12. Transfer                   | 25. LCD panel display (backlit)  |
| 13. Auto Dial/Store            |                                  |

### Making Calls

#### Calling another extension




## Calling an outside party




## Call Control

### Transferring a call to an extension



### Conference calls



## Speed Dial

### Access personal speed dial

