


NUMBER:	UG14007
CATEGORY:	User Guide
DATE:	29/07/2016
VERSION:	1.1

Panasonic KX-NT551 – Quick Reference Guide


The Handset




- | | |
|--------------------------------|----------------------|
| 1. LCD panel display (backlit) | 10. Redial |
| 2. Message waiting lamp | 11. Auto Ans/Mute |
| 3. Programmable keys | 12. Transfer |
| 4. Handset hook | 13. Auto Dial/Store |
| 5. Headset jack (corded) | 14. Hold |
| 6. Pause | 15. Intercom |
| 7. Conf (conference) | 16. SP-Phone |
| 8. Message | 17. Microphone |
| 9. Flash/Recall | 18. Navigation panel |

Making Calls

Calling another extension




Calling an outside party




Call Control

Transferring a call to an extension



Conference calls



Speed Dial

Access personal speed dial

